

Operating Instructions for #82376 Right Angle Sander/Drill

1. Use your Right Angle Grinder with a 12 volt DC power source only. If you are not using our Variable Speed Transformer you must observe polarity. Changing polarity (+ to - or - to +) on any DC motor will cause the tool to run in reverse. Sanding disk must turn clockwise when viewed from the back.
2. Don't force tool. It will do the job better and safer at the rate for which it was designed.
3. Replace sanding disks and other accessories as soon as wear is apparent.
4. Use hex key supplied to remove sanding pad or to affix drilling accessories.

CAUTION

Unplug tool before changing sanding disks or accessories.

Always be aware of the rotating disk or bits which can abrade skin easily.

Secure work. Use clamps or a vise to hold work whenever possible.

Wear eye protection.

Do not operate tool after taking drugs, alcohol or medications or when you are tired or fatigued.

Keep long hair tied back.

Do not wear loose clothing.

Keep tool out of reach of children.

Operating Instructions for #82376 Right Angle Sander/Drill

1. Use your Right Angle Grinder with a 12 volt DC power source only. If you are not using our Variable Speed Transformer you must observe polarity. Changing polarity (+ to - or - to +) on any DC motor will cause the tool to run in reverse. Sanding disk must turn clockwise when viewed from the back.
2. Don't force tool. It will do the job better and safer at the rate for which it was designed.
3. Replace sanding disks and other accessories as soon as wear is apparent.
4. Use hex key supplied to remove sanding pad or to affix drilling accessories.

CAUTION

Unplug tool before changing sanding disks or accessories.

Always be aware of the rotating disk or bits which can abrade skin easily.

Secure work. Use clamps or a vise to hold work whenever possible.

Wear eye protection.

Do not operate tool after taking drugs, alcohol or medications or when you are tired or fatigued.

Keep long hair tied back.

Do not wear loose clothing.

Keep tool out of reach of children.

Micro-Mark[®] 340 Snyder Avenue
Berkeley Heights, NJ 07922
Tech Support: Tech@micromark.com
www.micromark.com

MM122316

Micro-Mark[®] 340 Snyder Avenue
Berkeley Heights, NJ 07922
Tech Support: Tech@micromark.com
www.micromark.com

MM122316

Operating Instructions for #82376 Right Angle Sander/Drill

1. Use your Right Angle Grinder with a 12 volt DC power source only. If you are not using our Variable Speed Transformer you must observe polarity. Changing polarity (+ to - or - to +) on any DC motor will cause the tool to run in reverse. Sanding disk must turn clockwise when viewed from the back.
2. Don't force tool. It will do the job better and safer at the rate for which it was designed.
3. Replace sanding disks and other accessories as soon as wear is apparent.
4. Use hex key supplied to remove sanding pad or to affix drilling accessories.

CAUTION

Unplug tool before changing sanding disks or accessories.

Always be aware of the rotating disk or bits which can abrade skin easily.

Secure work. Use clamps or a vise to hold work whenever possible.

Wear eye protection.

Do not operate tool after taking drugs, alcohol or medications or when you are tired or fatigued.

Keep long hair tied back.

Do not wear loose clothing.

Keep tool out of reach of children.

Operating Instructions for #82376 Right Angle Sander/Drill

1. Use your Right Angle Grinder with a 12 volt DC power source only. If you are not using our Variable Speed Transformer you must observe polarity. Changing polarity (+ to - or - to +) on any DC motor will cause the tool to run in reverse. Sanding disk must turn clockwise when viewed from the back.
2. Don't force tool. It will do the job better and safer at the rate for which it was designed.
3. Replace sanding disks and other accessories as soon as wear is apparent.
4. Use hex key supplied to remove sanding pad or to affix drilling accessories.

CAUTION

Unplug tool before changing sanding disks or accessories.

Always be aware of the rotating disk or bits which can abrade skin easily.

Secure work. Use clamps or a vise to hold work whenever possible.

Wear eye protection.

Do not operate tool after taking drugs, alcohol or medications or when you are tired or fatigued.

Keep long hair tied back.

Do not wear loose clothing.

Keep tool out of reach of children.

Micro-Mark[®] 340 Snyder Avenue
Berkeley Heights, NJ 07922
Tech Support: Tech@micromark.com
www.micromark.com

MM122316

Micro-Mark[®] 340 Snyder Avenue
Berkeley Heights, NJ 07922
Tech Support: Tech@micromark.com
www.micromark.com

MM122316